



Bohr-Fixx - Praktischer Lochsägenhalter entfernt den Bohrkern automatisch

- » Automatischer Auswurf des Bohrkerns
- » Einfaches Wechseln der Lochsäge
- » Aufnahme für Lochsägen ab 38 bis 127 mm
- » Auch einzeln erhältlich
- Geeignet für Gipskarton- und Gipsfaserplatten, Holz und Metall
- » Bitte beachten Sie die Drehzahl-Tabelle!

Serie	-
Artikelnummer	P779
Kategorie	Werkzeuge
Montageart	-
Einsatz	-
EAN	4260182063781

Produkteigenschaften

Aufnahme für Lochsägen ab	Ø 38 mm
Zentrierbohrer	Ø 6,35 mm
Länge Zentrierbohrer	75 mm
Metallochsäge	Ø 68 mm





Bohr-fixx - Practical hole saw holder automatically removes the drill core

- » Automatic ejection of the drill core
- » Easy change of the hole saw
- » Holder for hole saws from 38 to 127 mm
- » Also available individually
- Suitable for plasterboard and gypsum fiberboard, wood and metal
- » Please note the speed table!

Series	-
Article No.	P779
Category	Tools
Type of installation	
Use	-
EAN	4260182063781

Product features

Holder for hole saws from	Ø 38 mm
Center drill	Ø 6,35 mm
Length center drill	75 mm
Metal hole saw	Ø 68 mm